
## **EQOair Aluminium Coupling**

Coupling	Part N.	ø	Fig.	A	E	L	s	gr.
	8010.020	20	А	70,0	37,0	35,0	29,0	72,0
	8010.025	25	Α	75,0	42,0	37,0	36,0	96,0
	8010.032	32	Α	94,0	51,0	46,0	43,0	174,0
	8010.040	40	Α	117,0	63,0	57,0	53,0	338, <b>0</b>
	8010.050	50	Α	138,0	78,5	68,0	66,0	554,0
	8010.063	63	Α	173,0	95,0	83,0	82,0	990,0
	8010.075	75	Α	174,0	108,5	85,5	100,0	1.140,0
a 14	8010.090	90	Α	190,0	132,0	<b>9</b> 3, <b>0</b>	118,0	1.760,0
	8010.110	110	В	150,0	206,0	73,0	154,0	2.175,0
	8010.160	160	В	272,0	266,0	133,5	221,0	7.800,0



Technical Details								
	EQO <i>air</i>							
Standard Colour	RAL 5012							
Max Working Pressure	16 bar							
Plant Testing Pressure 1 hour at 20°C	24 bər							
Quality Testing Pressure 1 hour at 20°C	72 bar							
Production tested percentage	1%							
O.Ring & Lip Gasket Material	NBR 65/75 S.A							
Continuous Service Temperature Limit	-30°C - 120°C							
Aluminium Pipe Mechanical Resistance	According to EN-755-2/2008 standards							
Pipe Material	Aluminium alloy EN AW 6060 - T5 according to EN 755-2/2008							
Pipe Thickness mm	Tube lenght tollerance +0 -0,1%							
Aluminium Fittings Material	Aluminium Alloy EN Aw 6061 T6 / ENAB 42000							
Clamp Ring Material	AISI 304 Stainless Steel							
Threads Standards	BSPT - British standard pipe taper - ISO 7-1							
Pipe Surface treatement	Polyester resin coated							

## Components (DN20 - DN90)



- 1. Nut
- 2. Identifcation Ring
- 3. Clamping Ring
- 4. O-Ring
- 5. Body

#### Components (DN110 - DN160)



- 1. Half Blocking Ring
- 2. Lip Seal
- 3. Clamping Ring
- 4 Identification Mark Holder
- 5. Body
- 6. Bolts

#### Preperation

Verify the integrity of the pipe section to be inserted in the ftting.

Any scratches on the paint, if not deep, can be eliminated using 300-600 fine emery paper.

Deep dents/scratches can be eliminated only by changing the branch position or by replacing the pipe section.

When necessary, cut the pipe with a neat 90° cut. Carefully deburring the internal and external sharp resulting edges and make an external bevel of 2-4 mm length with a 30° taper.


All pipe supplied should be deburred internally, externally and beveled.


Mark the pipe so to have a reference for its correct insertion into the ftting to make sure it exceeds the gasket.

The table below shows the correct reference lengths.

DN	20	25	32	40	50	63	90
L(mm)	35	38	49	60	76	96	<b>9</b> 3

Lubricate the marked pipe section.





#### Assembly

Loosen the nut until the clamp ring is loose.

Ensure the pipe and fittings are parallel to each other.

Insert the pipe into the ftting up to align the reference mark with the external nut surface.

Tighten the nut by hand. In this case, the water tightness and axial clamping are ensured.







### Assembly (DN110 - DN160)

Loosen the bolts of the ftting.

Ensure the pipe and fittings are parallel to each other.

Insert the pipe into the ftting up to align the reference mark with the external blocking ring surface.

Tighten all the bolts at a torque value of 15 N/m.

